

OrthaPrime

Primer for Rubber

Technical characteristics & usage advice

For the perfect bond when working with rubber materials

One component Primer for Thermoplastic Rubber, Neoprene and Natural Rubber. Commonly used to prepare rubber sole units and sheet rubber in the manufacture or repair of footwear.

Features and Benefits:

- Allows for perfect adhesion of commonly difficult to bond rubber materials.
- Excellent for use with any Aortha adhesives.
- Budget friendly prices.

Application: by brush (without metallic parts)

Drying time before bonding: 60 mins

Storage: Keep in cool place - protect from direct light

Application:

Once applied to a material the halogenation process keeps the applied surface in an activated state ready for bonding. Storage at this point is important to avoid premature ageing of the component.

Take care in dusty or humid environments with high temperature variations.

Ordering Information:

RA1291 1 Litre

Warnings:

- Never use with Metallic parts.
- Avoid contact with skin or eyes.
- Protect hands with rubber gloves at all times.
- Use in well ventilated room.

